


AIRBAG SYSTEM Manual

※Read carefully before use.



AIRBAG JACKET USER'S GUIDE



For Motorcycle
< Y-type Key Box >

www.hit-air.com

MUGEN DENKO CO., LTD.

1-1012 Ikeba Tempaku-ku Nagoya 468-0055 JAPAN
phone +81-52-807-7750 fax +81-52-807-7901
E-mail mugen@hit-air.com
URL www.hit-air.com

HAM-MC-Y-E210422

⚠ Be sure to read this page before using and after re-assembling the Hit-Air.

Thank you for using the Hit-Air.
For your safety, peace of mind and correct use of your airbag jacket,
make sure that items ① - ⑤ are confirmed before use as follows:

Caution ⚠

- Unless the Hit-Air is set correctly, it may not work or may cause a malfunction.
- Once a CO² cartridge is activated, it cannot be used again. Remove it from the key box without fail.
- Use a Hit-Air CO² cartridge only. Do not use any other one.

① A CO² cartridge of the right size (capacity) for the model is installed.

The seal attached the cartridge shows its size (capacity).

② Sealed properly (No damage to the seal)

*No seal is attached in case re-assembling is done by yourself.

Unused CO² cartridge and the key box are properly sealed at the time of shipment. (*The key ball is set)

- The right size (capacity) cartridge for the model is installed.
- A CO² cartridge is tightly screwed into the key box.
- An used/empty cartridge should not be installed.

Caution ⚠ Re-assembling after the activation must be done in accordance with "Re-assembling Key Box" (see page 21 to 24)

③ Is there any deterioration of the wire loop or the coiled wire?




④ A screw hole at the bottom of the key box is visible.

(The setting bolt is removed)


⑤ A coiled wire is set properly.

See "Attaching Coiled wire to Motorcycle" (page 17 to 18)

⚠ Be sure to tie a knot tightly.



① The size (capacity) of the cartridge varies from model to model. Make sure that the size (capacity) shown on the seal attached to the CO² cartridge and that shown at the back of the key box cover are the same. (*Some model has no size label attached)



*If sizes shown as above are not the same, it may cause a malfunction.


*If the right size for the model is not clear, check it against the Hit-Air catalogue, or visit our website

<http://www.hit-air.com>
"Replacement gas cartridge list"

*A description of the size label varies from model to model.

② If the CO² cartridge and the key box are not sealed or if the seal attached is torn at the time of the purchase of a new product, remove the cartridge and make sure that there is no hole at its bottom (at the screw end)


If there is no hole - it is an unused cartridge to be installed in the key box for use.



*An unused cartridge is to be installed in accordance with "Re-assembling Key Box" (see page 21 to 24).

③ Is there any deterioration of the wire loop or the coiled wire? If so, replace it with a new one. Its replacement in every 1 to 2 years is recommendable.

④ Make sure that the setting bolt has been removed from the key box.



The setting bolt is a tool to be used for setting the key ball into the hole of the key box for re-assembling. (see page 23 in detail).

*The Hit-Air will not be activated if the setting bolt remains in the key box. Make sure that the setting bolt is removed from the key box before using the Hit-Air.

⑤ Tie a knot tightly to fix a coiled wire to the saddle, A knot works as the stopper to prevent the wire coming off when the Hit-Air is activated.

Caution ⚠ Without a knot, the wire may come off the Hit-Air at its activation and the airbag will not inflate.

Be sure to read this User's Guide to use the Hit-Air properly. A maintenance check by an authorized dealer once a year is recommendable for your safety and peace of mind.

- Thank you for your purchase.
- For the proper use of the Hit Air, please read this booklet carefully before use.
- Please carry this booklet together whenever you use the Hit Air.

▶▶▶ 1	Safety Precautions	5
▶▶▶ 2	General Information	7
▶▶▶ 3	Name and Shape	9
▶▶▶ 4	Structure	11
4-1	Function	11
4-2	Air Cushion	11
4-3	Key Box (Y-type)	12
4-4	Key Ball (Y-type)	13
4-5	CO ₂ Gas Cartridge	13
4-6	Hit-Air Structure	14
▶▶▶ 5	Using Hit-Air	15
5-1	One-touch Release	15
5-2	Connecting Coiled Wire and Jacket with Hit-Air	15
5-3	Attaching Coiled Wire to Motorcycle	16
5-4	Where and how to fix a Coiled Wire	17
▶▶▶ 6	Attention after Activation	19
▶▶▶ 7	Re-assembling Hit-Air after Activation	20
7-1	How to Re-assemble	20
7-2	Re-assembling Key Box	21
▶▶▶ 8	Dismantling and Assembling of Hit-Air inner system	25
8-1	How to dismantle the Hit-Air inner system	25
8-2	How to assemble (the reverse of dismantling)	27
▶▶▶ 9	Washing	30
▶▶▶ 10	How to Store	30
▶▶▶ 11	Change	30

Tools for Re-assembling

Hexagon wrench (5mm)
Setting bolt
Protector tube
Wire Loop
One-touch Connector Female
One-touch Connector Male
Cap
Tie a knot tightly

CO₂ gas cartridge (See P.13)
When the key box is activated, the gas cartridge releases CO₂ gas into the airbag (to each air cushion) immediately to inflate them.

Key box (Y-type) (See P.12)
Jointly developed by YKK and Mugen Denko

Key ball (Y-type) (See P.13)
Key ball to be pulled out to release the gas into the airbag instant!
Key ring holds a key ball in the key box.

One-touch release(Connector) (See P.15)
When getting on a motorcycle, connect the male connector at the end of the coiled wire attached to the motorcycle with the female connector attached to the jacket.

Loop setter (See P.16)
After a coiled wire is fixed to a motorcycle and its length is adjusted, place it in the grooves of the loop setter and tighten the wing screw.

Coiled wire (See P.16)
A strong wire of Kevlar cord coated with urethane resin.

Protector tube (See P.16)
Protect a motorcycle and a coiled wire against damage.
Pass a coiled wire through a protector tube to protect the part of the wire wound round the frame or handlebar etc. of the motorcycle. Cut the excess tube depending on the part where the coiled wire is fixed.

1 Safety Precautions

Be sure to read this User's Guide carefully before using the jacket with the Hit-Air (shock-buffering system) for proper use and safety and keep it, in the place you can reach anytime (e.g. in the motorcycle).

The marks used in this User's Guide denote as follows.

WARNING



This mark denotes that if the "WARNING" is ignored, it could result in death or a serious injury to the user of this product.

- WARNING** 1. The jacket with the Hit-Air is to be used for the rider's safety when riding a motorcycle and not for any other purpose.
- WARNING** 2. The jacket with the Hit-Air of the right size is to be worn as an outerwear on the upper half of the body.
- WARNING** 3. Use the gas cartridge of the same size and contents as before when replacing and confirm that there are no holes or tears in its seal.
- WARNING** 4. Do not take any parts of the Hit-Air apart.
- CAUTION** 5. Remove sharp on pointed objects such as pins or pens from the jacket with the Hit-Air or from the underwear before wearing. They may damage the air cushion before or at the time of the activation and prevent the function of the Hit-Air.
- CAUTION** 6. Keep open flames and cigarettes away from the jacket with the Hit-Air as holes or tears caused by them will prevent its function. Keep and use at temperatures below 40°C/104°F as the gas cartridge may burst at a high temperature.
- CAUTION** 7. Disconnect the Hit-Air from the "coiled wire" at the "one-touch release (connector)" before dismantling the motorcycle. Otherwise, it may cause an accidental activation.
- CAUTION** 8. Inspect the Hit-Air to determine if there is any damaged prior to wearing. If there is any damage, consult with an authorized dealer.

CAUTION





This mark denotes that if the "CAUTION" is ignored, it could result in a physical injury or a material damage.

- CAUTION** 9. To make sure the Hit-Air will function properly, take it to an authorized dealer for a maintenance check, once a year depending on frequency of use.
- CAUTION** 10. Keep the jacket with the Hit-Air by hanging up on a coat hanger. Do not fold or lay anything on it. Avoid high temperature and high humidity.
- CAUTION** 11. To avoid any damage to the airbag, do not prick a needle or sew emblems or iron on the jacket with the Hit-Air. Consult with an authorize dealer where to sew an emblem.
- CAUTION** 12. Make sure the "coiled wire" is securely attached to the motorcycle. Improper attaching may prevent the function of the Hit-Air.
- CAUTION** 13. Take full responsibility for correct removing and replacing of the Hit-Air inner system.
- CAUTION** 14. Don't use a Hit-Air inner system (shock buffering protection system) separately from the vest or jacket.
- CAUTION** 15. Don't wash a Hit-Air inner system. Remove it from the vest or jacket and wash the vest or jacket only.
- CAUTION** 16. If a fray, rust or wear is found on the "wire loop" or the "coiled wire" attached to the "key ball", replace it immediately.



When getting on the motorcycle, connect "one-touch release(connector)"



The jacket with the Hit-Air (Shock-buffering Protection System) is to be worn as an outerwear when riding a motorcycle.

It will be activated/inflated immediately after a distance from the rider to the motorcycle exceeds the "activation distance" (*1) when the rider falls off or thrown off the motorcycle. It will be activated at the moment the key ball is pulled out from the key box (see 4-3 P12). This causes the gas cartridge to release the CO₂ gas into the air cushions to inflate them immediately.

Inflated air cushions are designed to come between the rider's body and objects against which the rider may strike after falling off or being thrown off the motorcycle.

The Hit-Air will act as a buffer to absorb the shock of impact and reduce the risk of injury the rider who wears it.

However, this does not imply or guarantee rider's safety.

The key ball requires considerable strength to be pulled out and will not be released easily because of the elastic nature of the coiled wire, thus the Hit-Air will not inflate under normally anticipated riding conditions including standing on pegs.

(*1) The "activation distance" is defined as the length of the coiled wire stretched to its full length from the motorcycle to the rider's key box on the Hit-Air without any obstacles in between.

- If the "coiled wire" running from the "key box" to the motorcycle touches an obstacle such as the rider's body, any part of the motorcycle, a whip or any other projecting object, there is a possibility of accidental activation within the "activation distance" by a force strong enough to pull the "key ball" out of the "key box".
- If the rider crashes or falls down together with the motorcycle, unless the "activation distance" is exceeded, the Hit-Air will not be activated. The Hit-Air will not protect areas where the inflated air cushion does not cover.
- If the rider wearing the Hit-Air forgets to disconnect the "one-touch release" and goes away from the motorcycle farther than the "activation distance", a force of approximately 20kg-35kg (see 4-3 P12) may activate and inflate the Hit-Air. Connect or disconnect the "one-touch release" while you are on the motorcycle.
- Once a gas cartridge is used, it cannot be used again. Buy a new one from an authorized dealer.

Key Box
A CO₂ cartridge is placed at the bottom of the airbag.

Front / before

Slit (opening) for neck cushion to go through.

Key ball to be pulled out to release the gas into the airbag instantly.

Front / after

Neck cushion

*Design and shape of model may vary.

Jacket and Vest type

Back / before

Key ball to be pulled out to release the gas into the airbag instantly.

Back / after

*Packed type hip cushion inflates right away.

*Design and shape of model may vary.

4-1 Function

1. As soon as the "activation distance" is reached, the Hit-Air is activated and the CO₂ gas is sent into the air cushions so that it will provide protection from the shock of impact even before it is fully inflated.
2. The CO₂ gas cartridge and the "key box" area is covered by an ABS protector with buffer material to protect the rider's breast from the projecting objects in case of an accident.
3. After the airbag is inflated in full, the gas will leak out gradually. Depending on the amount of the pressure given to the airbag by the accident, a feeling of tightness may be felt but gradually subsides.

CAUTION ⚠

4. The Hit-Air may not function properly, if there is a damage to the Hit-Air, cloth of the wear, air cushion, Velcro, zipper, buckle etc. If so, consult with an authorized dealer. The Hit-Air may not be repairable in some cases.

CAUTION ⚠

5. Whenever the Hit-Air is inflated, even if there is no visible damage, we recommend taking the Hit-air to an authorized dealer for a maintenance check *1

*1 Even if no damage is visible, there may be damages to the air cushion. Therefore, take the Hit-Air to an authorized dealer for a maintenance check to test the air cushion for leaks and inspect its parts to make sure it will function properly in case of an accident.

4-2 Air Cushion

1. The air cushions are made of high quality strong urethane film to absorb and reduce the shock of impact as much as possible when they are swollen.
 2. The maximum pressure is about 30kpa(0.3kg/cm²) when the air cushion is fully inflated, but gradually decreases as gas comes out of the air cushion.
 3. The strength against breakage depends on the material of the jacket the material of the inner tube (urethane) and the strength of the stitch it also depends on the degree of impact, shape or hardness of the object the rider may hit after the Hit-Air inflates.
 4. The gas is sent from the "key box" to each air cushion through urethane tubing.
- The Hit-Air is designed to act as a shock absorber and may break depending on the shape of the object against which it strikes and also the extent of impact given.

4-3 Key Box (Y-type)

With a tensile strength of approximately 30kg-35kg by the "coiled wire", the "key ball" comes out of the "key box". Then a needle in the "key box" is activated and punctures the seal of the gas cartridge to inflate the Hit Air instantly.


The "key ball" can be pulled out from any direction (Photo 1).

CAUTION ⚠


1. Do not take the "key box" a part or remove any part.

CAUTION ⚠

2. Screw in the gas cartridge fully until it seats firmly but do not over tighten. If anything wrong, consult with an authorized dealer.




Key box structure



4-4 Key Ball (Y-type)

The key ball holds a compression spring and an interlocking needle in the key box. When the system is activated, the key ball comes out of the key box and a needle in the key box is released and punctures the seal of the gas cartridge to inflate the Hit Air immediately.



The key ball and the key ring are integrated parts.

4-5 CO₂ Gas Cartridge


- The gas cartridge contains CO₂ gas.
- When the "key ball" is released from the "key box", a needle punctures the seal of the gas cartridge to let the gas go into each air cushion.
- Screw the CO₂ cartridge fully into the bottom until it cannot go any further. Otherwise, a needle in the "key box" may not puncture the seal of the CO₂ cartridge and Hit-Air may not be activated properly.
- Do not reuse the gas cartridge once used. Change it to a new one. The seal at the bottom of an used cartridge is pierced with a hole.

Observe the followings to avoid an explosion

- WARNING** ⚠ 1. Keep and use at the temperature below 40°C/104°F. Do not keep in the car where the temperature may go up high.
- WARNING** ⚠ 2. Do not give the cartridge a strong shock.
- WARNING** ⚠ 3. Do not heat the cartridge.
- WARNING** ⚠ 4. Do not let corrosion form on the surface of the cartridge. If corrosion is noticed, replace it immediately.
- WARNING** ⚠ 5. Confirm that the used gas cartridge is empty of gas before disposing.
- WARNING** ⚠ 6. Do not cut or puncture the gas cartridge.
- WARNING** ⚠ 7. The size (capacity) of the gas cartridge varies from model to model. Install the designated size (capacity) for the model. Visit <http://www.hit-air.com> "Replacement Gas Cartridges list" to find out the right size for the jacket.
- CAUTION** ⚠ 8. Use the gas cartridge for the Hit-Air only, and not for any other purpose.
- CAUTION** ⚠ 9. Use a Hit-Air CO₂ gas cartridge only. Do not use any other one.
- CAUTION** ⚠ 10. Keep the gas cartridges out of the reach of children.
- CAUTION** ⚠ 11. Once the gas cartridge is installed, don't attempt to turn, loosen or remove it.
- CAUTION** ⚠ 12. Screw the CO₂ cartridge fully until it seats firmly in the key box but do not over tighten.

4-6 Hit-Air Structure

Hit-Air inner system is attachable to or removable from the jacket or vest in the same way with buttons, zipper or Velcro.




*Shape of model may vary.

5 Using Hit-Air

5-1 One-touch Release

Use the "one-touch release" for easy connection or disconnection of the "coiled wire" attached to the motorcycle and the "key ball" inserted in the "key box".





CAUTION ⚠

- The one-touch release may come in contact with and cause damage to the tank or other part of the motorcycle. If such situation is expected, putting a seal around such parts for protection is recommended.
- Hold the female connector and insert the male one. A clicking sound will confirm that a connection is made properly. Otherwise, it may come off by itself.
- Change it for a new one if/when the insertion is not made properly. Using force to connect the one-touch release may cause its malfunction.
- When getting off the motorcycle, make sure that the male part does not touch the hot part of the motorcycle, such as the engine or muffler, because the heat could damage the optimal shape of the male part.

5-2 Connecting Coiled Wire and Jacket with Hit-Air

- Hold both sides of the female part of the "one-touch release" into which insert the male connector (Photo 1).
- Before getting off the motorcycle, press the press button of the "one-touch release" for disconnection (Photo 2).



*Shape and how to use the "one-touch release" may be different from the Photos 1 and 2.

WARNING ⚠ Before riding the motorcycle, make sure the red slide cover on the "key box" is in the 'unlocked (up)' position (see page 12, photo 2). If it is in the 'locked (down)' position, the Hit-Air will not work properly in case of accident etc.

15

5-3 Attaching Coiled Wire to Motorcycle

Where and how to attach the "coiled wire" to the motorcycle varies with the motorcycle. The rider's movement when riding also varies. Taking these into consideration, decide the length of the "coiled wire" and the part of the motorcycle where it is to be attached (see page 17 to 18). Improper attaching may cause an accidental activation of the Hit-Air when the rider touches the "coiled wire" with some force.

WARNING ⚠ 1. Fix the "coiled wire" not in use on the part of the motorcycle, to avoid the "coiled wire" touching the heated engine etc., obstructing rider's movement, coiling around the wheel and causing damages to it or the motorcycle. If such problem is foreseeable, remove the "coiled wire" from the motorcycle.

CAUTION ⚠ 2. Due to the elastic nature of the "coiled wire", the "key ball" or the "one-touch release" may hit the fuel tank or other part of the motorcycle causing damages when the Hit-Air is activated.


3. If the "coiled wire" is not attached to the motorcycle properly, it may come off when it is stretched then the Hit-Air will not be activated.

4. Replace the "coiled wire" when wear, burns, peeling or cracks are found.

*Do not use the coiled wire other than the one supplied by an authorized dealer.

Coiled Wire


A strong wire of Kevlar cord coated with urethane resin.



Loop setter

After a coiled wire is fixed to a motorcycle and its length is adjusted, place it in the grooves of the loop setter and tighten the wing screw.

- When getting on a motorcycle, confirm that the wing screw is tightly screwed down.
- Place a coiled wire in the grooves of the loop setter and tighten it firmly with the wing screw. Leave more than 2cm of the wire outside of the loop setter, cut any excess wire and cap the cut end.
- After the length of the wire is adjusted, tie a knot tightly. Otherwise, a wire may come off the loop setter and the airbag will not be activated.



Protector tube


Protect a motorcycle and a coiled wire against damage.

Pass a coiled wire through a protector tube to protect the part of the wire wound round the frame or handlebar etc. of the motorcycle. Cut the excess tube depending on the part where the coiled wire is fixed.


16

5-4 Where and how to fix a coiled wire.


Where and how to fix a coiled wire.



- 1 Wind the protector tube round a frame, adjust its length and cut the excess tube.




- 2 Pass the coiled wire through the protector tube.



- 3 Temporarily fix the coiled wire in the loop setter and adjust its length.




- 4 Determine the length of the coiled wire by standing on the pegs to make the coiled wire fully stretched.



- 5 Lastly, fix the wire firmly with the loop setter, knot it tightly, cut it leaving 2cm and cap the cut end.

- ⚠ Tie a knot** A knot works as a stopper of the wire.
1. Form a ring.
 2. Pass through the ring.
 3. Knot tightly.
- Closely Leave more than 2cm



- 6 Put the seat back.



Fix it to a frame on the right-hand side of the motorcycle.

Place to fix A: an inside frame under the seat.



B: an outside frame on the right.



Caution ⚠ Don't fix a coiled wire to any part where it would disturb driving the motorcycle, where it would lead to damage a part of the motorcycle, where it may come off when it is pulled and where it becomes hot (over 60°C) such as the engine or muffler.

17

5-4 How to adjust the length of a coiled wire.

How to adjust the length of a coiled wire.

Stand up on the pegs so as to make the coiled wire fully stretched.




Scooter example 1



A wire fixed to the neck of the handlebar. Standing on the scooter and the wire is at full stretch

Scooter example 2




A wire fixed to the seat. Standing on the ground and the wire is at full stretch.

Scooter example 3



A wire fixed to the rear seat. Standing on the rear step in a half-crouching position and the wire is at full length

Where to adjust and fix a coiled wire may vary depending on the size and make of the motorcycle as shown above.



[sold separately] Connector holder

To hold the free end of a coiled wire while it is not in use.

18

Pay attention when the jacket with the Hit Air is inflated as follows.

1. The jacket with Hit-Air is designed to provide protection especially to the wearer's neck, so when it is inflated, there will be some pressure around the neck, and if it is difficult to release the strap of helmet, take the Hit-Air off immediately.
2. Watching around the situation calmly, unzip and release the buckle to take off the jacket.
3. If the scene of accident seems to be dangerous, go to the safe area before taking off the jacket.
4. When the Hit-Air is inflated, a feeling of tightness may be felt, but the gas will leak out gradually. Therefore, calm yourself even if the body with the inflated jacket is pressed down by something.
5. If the air cushion is punctured when fully inflated, the gas in all the cushions will immediately escape and the cushions deflate.

CAUTION ⚠️ 6. If the Hit-Air inflates accidentally for some reason while riding, do not upset. Look for a safe place and take an appropriate action. To continue to ride with the inflated Hit-Air may be dangerous due to the increasing wind resistance etc. Remove it first.

CAUTION ⚠️ 7. If there is an external damage to the Hit-Air due to its activation, take it to an authorized dealer for a maintenance check and to replace the gas cartridge. In cases of extreme damages externally or internally, it may not be repairable.


CAUTION ⚠️ 8. Be aware of the points listed below when attempting to re-assemble the Hit-Air by yourself after it is activated.

- Whether it has external damages (holes, scratches, tears etc.)
- Confirm that the airbag is fully inflated when it is activated.
- Confirm that the gas cartridge to be replaced is the correct size and unused.

Go over the points listed above and if there are no problems, re-assemble the Hit-Air carefully at your own risk. It may not work as designed if there are external or internal damages. For further details for re-assembling see Chapter 7, (pages 20 to 24).

7-1 How to Re-assemble

We recommend to take the Hit-Air once activated to an authorized dealer for a maintenance check and re-assembling. It can be reused if it is re-assembled in accordance with the following procedure, but unless it is done properly, it may not work. It cannot be re-assembled if it is damaged by the previous activation.




Outline of re-assembling by yourself

- Get an unused CO² cartridge and tools for re-assembling ready. See.(P21)1
- ▼
- Unscrew the used cartridge. See.(P21) 2
- ▼
- Remove all CO² gas from the air cushion. See.(P21) 3
- ▼
- Set a key ball in the key box by using tools See.(P22 to 23) 4 to 8
- ▼
- Install an unused cartridge. See.(P24) 9
- ▼
- Put on the key box cover See.(P24) 10


7-2 Re-assembling Key Box

1. Get tools for re-assembling ready (Photo 1)
Get an unused CO² cartridge, a hexagon wrench and a setting bolt ready



CAUTION ⚠️
As the CO² cartridge for the jacket with the Hit Air varies in size (capacity), choose the right size of the cartridge matching the size of the wear.

2. Unscrew the used gas cartridge by turning anticlockwise. (Photo 2)



3. To remove all remaining gas from the air cushion, spread the Hit Air, face down on a flat smooth surface. By pressing down each cushion using your hands, knees and legs, remove gas completely. Do not fold or roll up the Hit Air to avoid damages inside. It may take time to release all the gas in the air cushion but it is necessary as it cannot be re-assembled with gas left remaining in any of the air cushion. (Photo 3)



CAUTION ⚠️
If the gas left remaining in any of the air cushion, it cannot be re-assembled.

4. Insert a setting bolt into the hole at the bottom of the key box and tighten up by hand (Photo 4). (As tightening the bolt, the hole for the key ball goes down.)



5. When it becomes too tight by hand, tighten it further with the hexagon wrench until the inside hole is placed at the center of the outside hole. (Photo 5)



6. Set the key ball in the hole (Photo 6)
Insert the "key ball" with a ring deeply into the hole of the "key box".
If it is blocked by the ring and does not come down, tighten or loosen the "setting bolt" and/or press down the edge of the ring around the key ball by the fingernail until the "key ring" fits in the hole.
Make sure that the key ring is completely settled down into the hole of the key box. (See Good Example)



WARNING ⚠️
If not, (See Bad Example), the key ball may come out spontaneously or with a slight pull to cause unwanted activation of the Hit Air

7-2 Re-assembling Key Box

7. Remove the setting bolt. (Photo 7)
Loosen the "setting bolt" by the 5 mm hexagon wrench to remove it.

WARNING ⚠
Remove the "setting bolt" from the "key box" without fail. Otherwise the Hit Air will not be activated.



WARNING ⚠

Remove the setting bolt without fail.

8. Re-pack all air cushions and fasten all buttons (Photo 8)

Photo 8


Jacket and Vest type



P.T.O.

23

9. Install an unused CO2 cartridge (Photo 9)
Screw an unused gas cartridge until it is firmly seated, do not over tighten. If there is a problem with fitment, consult with an authorized dealer.



Install an unused cartridge indicated on the seal attached to the cartridge.

Photo 9



CAUTION ⚠
If the cartridge is not seated completely and firmly, the Hit-Air may not be activated/inflate.

10. Take the female side of the one-touch connector out through the hole of the key box cover and close the key box cover. (Photo 10)

Photo 10

Jacket and Vest type



END

24


8 Dismantling and Assembling of Hit-Air inner system

Take the responsibility for correct dismantling and assembling.
In case of washing or mending of the vest/jacket, the Hit-Air has to be dismantled and assembled carefully and correctly, otherwise it may not work as originally intended or may be damaged. (*Harness type Hit-Air (all-in-one airbag) cannot be dismantled)

8-1 How to dismantle the Hit-Air inner system


Air cushions exposed to the outside of the vest/jacket are fastened with buttons and velcro.

1. Spread out the vest/jacket on a flat surface.




2. Unscrew the CO² cartridge to remove.

CAUTION ⚠
Never attempt to turn, loosen or remove the CO² cartridge except for reassembling.




3. Unfasten plastic buttons and Velcro of the neck and hip cushions.



P.T.O.


25

4. Fully open the front zipper and the zipper across the lower part of the inside of the vest/jacket.



Airbag systems are attached to the inside of the vest/jacket with zippers in 3 places, the back cushion(A) and the body cushion(B,C).

5. Open 3 zippers for the back cushion(A) and for the body cushion(B,C) of the inside of the vest/jacket.




The end of the neck cushion is joined to the body cushion with the fastener(C)

6. Open the fastener (C)
7. Unfasten metal buttons of the hip cushion in 3 places.

8. Take the end of the neck cushion out through the opening of the left shoulder, unfasten Velcro around the neck and pull it in the direction of an arrow to be separated from the vest/jacket.

*Packed hip cushion type has no hip Velcro and no fastener
Unfasten metal buttons of the hip cushion in 2 places.

CAUTION ⚠
Don't pull air cushions by force. It may cause damage to the Hit-Air.




P.T.O.

26

8-1

- Unfasten Velcro around the key box opening to separate from the vest/jacket. Take the Hit-Air system and shoulder, elbow and back protectors out and wash or launder the vest/jacket only in accordance with the washing instructions.

END




8-2 How to assemble (the reverse of dismantling)

- Spread out the vest/jacket on a flat surface, with the inside up, and open the zipper across the lower part of the inside of the vest/jacket

- Place the key box of the Hit-Air in the opening of the right-hand side of the vest/jacket and fasten it with Velcro on all sides.

Put the end of the key box plate first into the opening and fasten with Velcro on all sides.

P.T.O.



27

8-2

- Let the neck cushion go through from the inside of the right shoulder opening in the direction of an arrow. Then put its end into the left shoulder opening.

CAUTION ⚠

The neck cushion should not get twisted.

- Join the end of the neck cushion to the C zipper of the body cushion.
- Join 3 zippers of A and B to the inside of the vest/jacket.
- Take the hip cushion out through the hip opening, fasten 3 metal buttons and fix it to the right place with Velcro.




*For the packed hip cushion type, metal buttons to be fastened.

- Fasten the neck cushion with Velcro to the matching place of the vest/jacket.
Neck cushion Velcro
Shoulder 2 places, Neck 3 places.

- Fasten neck cushion plastic buttons on the shoulders and the back. (Shoulder 2 places, Neck 3 places)
Fasten hip cushion plastic buttons (3 places)

- Lastly, install a CO₂ cartridge and let the female side of the one-touch connector out through the hole of the key box cover and close the zipper. (See P25, 7-2, 9, for the installation of a CO₂ cartridge)

END



28

9 Washing

- Do not wash or launder the Hit Air (Shock-buffering Protection System).
- Take the Hit-Air system and protectors (shoulder, elbow, back etc.) out from the vest/jacket and wash or launder the vest/jacket only in accordance with the washing instructions. (See 4-7, page 16 to 18)
- Wipe the surface of the Hit-Air system (neck, hip cushions etc.) with a damp cloth to remove stains.

10 How to Store

For longer life and safety, avoid the following conditions:

- High temperature. (Under the direct sunlight, in the closed automobile, near the heater or open flames, etc.)
- Exposure to rain or extreme moisture, including steam and high humidity
- Storing items on top of the Hit-Air System / Jacket
- Leaving jacket within the reach of children, pets or other animals
- Folded or rolled up (Hang up on a coat hanger is preferable)

29

11 Change

If a problem listed below is found on the jacket with the Hit Air, consult with an authorized dealer to change or repair/replace.

- The jacket (cloth) or inner fabric (cloth) or inner fabric (cloth, mesh) becomes frayed or is torn and inner tubing (white urethane film) is exposed.
- A crack or rust is found on the "key box" or on the gas cartridge.
- The "coil wire" or the "wire loop" gets scraped and frays.
- Considerable change of color or deterioration of material.



hit-air
SHOCK BUFFERING SYSTEM

30